Aquaseal **Wet Room System**

CONTAINS ALL YOU NEED TO WATERPROOF 7.5M²

Waterproof Tanking Kit Contains:-

1 x 1 litre Waterproof **Tanking Primer**

1 x 5 litre Waterproof **Tanking Membrane**

1 x 10 metre Waterproof **Tanking Tape**

1 x Waterproof Tanking **Drain Mat**



Waterproof Tanking Membran

THE FOLLOWING PRODUCTS MAY **BE PURCHASED INDIVIDUALLY**

Waterproof Tanking Primer

For use before applying Tanking Membrane & Tanking Tape

Waterproof Tanking Membrane

Forms a permanently flexible watertight membrane, applied by brush, two coats.

Waterproof Tanking Tape

Self adhesive joint and corner sealing tape. Easy to apply with pre-cut release liner.

Waterproof Tanking Drain Mat

Self adhesive butyl backed fleece, capable of coping with movement around the drain outlet.



Wet Room System

Waterproof Tanking Kit



GOES BEHIND THE TILE SO **WATER DOESN'T!** Tel: 01-4510700 Fax: 01-4511600

Everbuild Building Products Ltd. Site 41, Knowsthorpe Way, Cross Green Industrial Estate, Leeds LS9 0SW

Tel: 0113 240 3456 Fax: 0113 240 0024 Website: www.everbuild.co.uk

Everbuild Ireland Unit A4, South City Business Park, Tallaght, Dublin 24

Why use the Aquaseal Wet Room System

The building materials generally used in modern domestic and commercial bathroom, shower and wet room areas such as plasterboard, plywood, MDF, softwood, blockwork and concrete are highly susceptible to water and excessive moisture and it is essential to protect both walls and floors prior to tiling. Failure to achieve a totally watertight seal behind tiled areas will almost certainly lead to water leakage.

- For showers, wet rooms and wet zones in bathrooms
- **■** For waterproofing before tiling
- Use on Plasterboard, MDF, Plywood, Cementitious Boards, Blockwork, Concrete & Specialist Wet Room Boards
- **■** Forms a permanently flexible watertight tank
- Can be used with underfloor heating
- **■** Easy to apply by brush
- Tested to BS/EN 14891
- Non Hazardous, solvent free



How to use the Aquaseal Wet Room System

The Waterproof Tanking Kit contains all you need to waterproof 7.5sq mtrs and consists of the following products used in the sequence as shown.



Step 1Waterproof Tanking Primer

A ready to use primer, applied by brush to all porous and semi porous surfaces in the areas that are to be waterproofed. It is quick drying and can be over coated after 1 hour.



Step 2 Waterproof Tanking Tape Waterproof

Tanking Tape is a self-adhesive joint & corner sealing butyl backed fleece tape that should be applied to all corner joints, board joints and pipe penetrations to provide a watertight seal that accommodates cross directional movement.





Finally, use Tanking Tape to seal all pipe entries.



Step 3 Waterproof Tanking Drain Mat

Fix the self adhesive Drain Mat, which is capable of coping with board movement around the drain outlet.

Use a drain matt when creating a bespoke shower. A drain matt isn't needed when using a preformed shower tray.



Step 4 Waterproof Tanking Membrane.

Apply the first coat of the ready to use liquid waterproofing compound by brush (sized 3 inches plus) using horizontal

strokes, to provide a permanently flexible waterproof membrane. Ensure the Tanking Membrane is applied generously and covers the Drain Mat and the Tanking Tape.



Step 5

After the first coat of Tanking Membrane is dry (6-12 hours) apply a second generous coat by brush ensuring the strokes are vertical, to create a permanent

waterproof barrier with a thickness of no less than 1mm



Step 6

After 24 hours drying, tiling can commence. It is recommended that a suitable waterproof tile adhesive and waterproof grout is used following the

application of the Aquaseal Wet Room System, and that all tiled corner joints are sealed with a waterproof and mould resistant silicone sealant such as Everbuild Forever White. Everbuild produce a wide range of Waterproof Tile Adhesive & Grouts that can be seen at www.everbuild.co.uk.

